

LECTURE 13

Procedure for Drawing Flow Nets:

At every **point** (x,z) where there is flow, there will be a value of head $h(x,z)$. In order to represent these values, contours of equal head are drawn.

A flow net is to be drawn by trial and error. For a given set of boundary conditions, the flow net will remain the same even if the direction of flow is reversed. Flow nets are constructed such that the head lost between successive **equipotential lines** is the same, say Δh . It is useful in visualising the flow in a soil to plot the flow lines, as these are lines that are tangential to the flow at any given point. The steps of construction are:

1. Mark all boundary conditions, and draw the flow cross section to some convenient scale.
2. Draw a coarse net which is consistent with the boundary conditions and which has orthogonal equipotential and flow lines. As it is usually easier to visualise the pattern of flow, start by drawing the flow lines first.
3. Modify the mesh such that it meets the conditions outlined above and the fields between adjacent flow lines and equipotential lines are 'square'.
4. Refine the flow net by repeating **step 3**.

The most common **boundary conditions** are:

- (a) A submerged permeable soil boundary is an equipotential line. This could have been determined by considering imaginary standpipes placed at the soil boundary, as for every point the water level in the standpipe would be the same as the water level. (Such a boundary is marked as CD and EF in the following figure.)
- (b) The boundary between permeable and impermeable soil materials is a flow line (This is marked as AB in the same figure).
- (c) Equipotential lines intersecting a phreatic surface do so at equal vertical intervals.