

# Chapter 40

## Traffic rotaries

### 40.1 Overview

Rotary intersections or roundabouts are special form of at-grade intersections laid out for the movement of traffic in one direction round a central traffic island. Essentially all the major conflicts at an intersection namely the collision between through and right-turn movements are converted into milder conflicts namely merging and diverging. The vehicles entering the rotary are gently forced to move in a clockwise direction in orderly fashion. They then weave out of the rotary to the desired direction. The benefits, design principles, capacity of rotary etc. will be discussed in this chapter.

### 40.2 Advantages and disadvantages of rotary

The key advantages of the rotary intersection are listed below:

1. Traffic flow is regulated to only one direction of movement, thus eliminating severe conflicts between crossing movements.
2. All the vehicles entering the rotary are gently forced to reduce the speed and continue to move at slower speed. Thus, more of the vehicles need to be stopped.
3. Because of lower speed of negotiation and elimination of severe conflicts, accidents and their severity are much less in rotaries.
4. Rotaries are self governing and do not need practically any control by police or traffic signals.
5. They are ideally suited for moderate traffic, especially with irregular geometry, or intersections with more than three or four approaches.

Although rotaries offer some distinct advantages, there are few specific limitations for rotaries which are listed below.

1. All the vehicles are forced to slow down and negotiate the intersection. Therefore the cumulative delay will be much higher than channelized intersection.
2. Even when there is relatively low traffic, the vehicles are forced to reduce their speed.
3. Rotaries require large area of relatively flat land making them costly at urban areas.
4. Since the vehicles are not stopping, and the vehicles accelerate at rotary exits, they are not suitable when there is high pedestrian movements.

### 40.3 Guidelines for the selection of rotaries

Rotaries are not suitable for every location. There are few guidelines that help in deciding the suitability of a rotary. They are:

1. Rotaries are suitable when the traffic entering from all the four approaches are relatively equal.
2. A total volume of about 3000 vehicles per hour can be considered as the upper limiting case and a volume of 500 vehicles per hour is the lower limit.
3. A rotary is very beneficial when the proportion of the right-turn traffic is very high; typically it is suitable for more than 30 percent.
4. Rotaries are suitable when there are more than four approaches, or if there is no suitable lanes available for right-turn traffic.

### 40.4 Traffic operations in a rotary

As noted earlier, the traffic operations at a rotary are three; diverging, merging and weaving. All the other conflicts are converted into these three less severe conflicts.

1. Diverging: It is a traffic operation when the vehicles moving in one direction is separated into different streams according to their destinations.
2. Merging: Merging is the opposite of diverging, when traffic streams coming from various places and going to a common destination are joined together into a single stream it is referred to as merging.
3. Weaving: Weaving is the combined movement of both the merging and diverging movements in the same direction.

These movements are shown in figure 40:1.

It can be observed that movements from each direction split into three; left, straight, and right turn. The major design aspect of a rotary is the design of the length and width of the weaving section.

#### 40.4.1 Design elements

The design elements include design speed, radius at entry, exit and the central island, weaving length and width, entry and exit widths. In addition the capacity of the rotary can also be determined by using some empirical formulae. A typical intersection is shown in figure 40:2

#### 40.4.2 Design speed

All the vehicles are required to reduce their speed at a rotary. Therefore, the design speed of a rotary will be much lower than the roads leading to it. Although it is possible to design roundabout without much speed reduction, the geometry may lead to large size incurring huge cost of construction. The normal practice is to keep the design speed as 30 and 40 kmph for urban and rural areas respectively.




Figure 40:1: Traffic operations in a rotary




Figure 40:2: Design of a rotary

### 40.4.3 Entry, exit and island radius

The radius at the entry depends on various factors like design speed, superelevation, and coefficient of friction. The entry to the rotary is not straight, but a small curvature is introduced. This will force the driver to reduce the speed. The speed range of about 20 kmph and 25 kmph is ideal for an urban and rural design respectively.

The exit radius should be higher than the entry radius and the radius of the rotary island so that the vehicles will discharge from the rotary at a higher rate. A general practice is to keep the exit radius as 1.5 to 2 times the entry radius. However, if pedestrian movement is higher at the exit approach, then the exit radius could be set as same as that of the entry radius.

The radius of the central island is governed by the design speed, and the radius of the entry curve. The radius of the central island, in practice, is given a slightly higher reading so that the movement of the traffic already in the rotary will have priority of movement. The radius of the central island which is about 1.3 times that of the entry curve is adequate for all practical purposes.

### 40.4.4 Width of the rotary

The entry width and exit width of the rotary is governed by the traffic entering and leaving the intersection and the width of the approaching road. The width of the carriageway at entry and exit will be lower than the width of the carriageway at the approaches to enable reduction of speed. IRC suggests that a two lane road of 7m width should be kept as 7m for urban roads and 6.5m for rural roads. Further, a three lane road of 10.5m is to be reduced to 7 and 7.5m respectively for urban and rural roads.

The width of the weaving section should be higher than the width at entry and exit. Normally this will be one lane more than the average entry and exit width. Thus weaving width is given as,

$$w_{weaving} = \left( \frac{e_1 + e_2}{2} \right) + 3.5m \quad (40.1)$$

where  $e_1$  is the width of the carriageway at the entry and  $e_2$  is the carriageway width at exit.

Weaving length determines how smoothly the traffic can merge and diverge. It is decided based on many factors such as weaving width, proportion of weaving traffic to the non-weaving traffic etc. This can be best achieved by making the ratio of weaving length to the weaving width very high. A ratio of 4 is the minimum value suggested by IRC. Very large weaving length is also dangerous, as it may encourage over-speeding.

## 40.5 Capacity

The capacity of rotary is determined by the capacity of each weaving section. Transportation road research lab (TRL) proposed the following empirical formula to find the capacity of the weaving section.

$$Q_w = \frac{280w[1 + \frac{e}{w}][1 - \frac{p}{3}]}{1 + \frac{w}{l}} \quad (40.2)$$

where  $e$  is the average entry and exit width, i.e.,  $\frac{(e_1 + e_2)}{2}$ ,  $w$  is the weaving width,  $l$  is the length of weaving, and  $p$  is the proportion of weaving traffic to the non-weaving traffic. Figure 40:3 shows four types of movements at a weaving section, a and d are the non-weaving traffic and b and c are the weaving traffic. Therefore,

$$p = \frac{b + c}{a + b + c + d} \quad (40.3)$$

This formula is valid only if the following conditions are satisfied.




Figure 40:3: Weaving operation in a rotary




Figure 40:4: Traffic approaching the rotary

1. Weaving width at the rotary is in between 6 and 18 metres.
2. The ratio of average width of the carriage way at entry and exit to the weaving width is in the range of 0.4 to 1.
3. The ratio of weaving width to weaving length of the roundabout is in between 0.12 and 0.4.
4. The proportion of weaving traffic to non-weaving traffic in the rotary is in the range of 0.4 and 1.
5. The weaving length available at the intersection is in between 18 and 90.

### Example

The width of a carriage way approaching an intersection is given as 15m. The entry and exit width at the rotary is 10m. The traffic approaching the intersection from the four sides is shown in the figure 40:4 below.

Find the capacity of the rotary using the given data. The traffic from the four approaches negotiating through the roundabout is illustrated in figure 40:7.

Weaving width is calculated as,  $w = \left[ \frac{e_1 + e_2}{2} \right] + 3.5 = 13.5\text{m}$

Weaving length,  $l = 4 \times w = 54\text{m}$

The proportion of weaving traffic to the non-weaving traffic in all the four approaches is found out first. It is clear from equation 40.2 that the highest proportion of weaving traffic to non-weaving traffic will give the




Figure 40:5: Traffic negotiating a rotary




Figure 40:6: Traffic weaving in East-South direction

minimum capacity. Let the proportion of weaving traffic to the non-weaving traffic in West-North direction be denoted as  $p_{WN}$ , in North-East direction as  $p_{NE}$ , in the East-South direction as  $p_{ES}$ , and finally in the South-West direction as  $p_{SW}$ . Then,

$$p_{WN} = \frac{505+510+350+600}{505+510+350+600+400+370} = \frac{1965}{2735} = 0.718$$

$$p_{NE} = \frac{650+375+505+370}{650+375+505+370+510+408} = \frac{1900}{2818} = 0.674$$

$$p_{ES} = \frac{510+650+500+600}{510+650+500+600+250+375} = \frac{2260}{2885} = 0.783$$

$$p_{SW} = \frac{350+370+500+375}{350+370+500+375+420+600} = \frac{1595}{2615} = 0.6099$$

Thus the proportion of weaving traffic to non-weaving traffic is more in the East-South direction.

The weaving traffic movements in the East-South direction is shown in figure ??.

Therefore, the capacity also need to be found only for that section.

$$\text{From equation 40.2, } Q_{ES} = \frac{280 \times 13.5 [1 + \frac{10}{13.5}] [1 - \frac{0.783}{3}]}{1 + \frac{13.5}{54}} = 2161.164 \text{ veh/hr.}$$

## 40.6 Summary

Traffic rotaries reduce the complexity of crossing traffic by forcing them into weaving operations. The shape and size of the rotary are determined by the traffic volume and share of turning movements. Capacity assessment of a rotary is done by analysing the section having the greatest proportion of weaving traffic. The analysis is




Figure 40:7: Traffic negotiating a rotary

done by using the formula given by TRL.

## 40.7 Problems

1. The width of approaches for a rotary intersection is 12 m. The entry and exit width at the rotary is 10 m. Table below gives the traffic from the four approaches, traversing the intersection. Find the capacity of the rotary.

Approach	Left turn	Straight	Right turn
North	400	700	300
South	350	370	420
East	200	450	550
West	350	500	520

The traffic from the four approaches negotiating through the roundabout is illustrated in figure 40:7.

Weaving width is calculated as,  $w = [\frac{e_1 + e_2}{2}] + 3.5 = 13.5\text{m}$

Weaving length,  $l = 4 \times w = 54\text{m}$

The proportion of weaving traffic to the non-weaving traffic in all the four approaches is found out first. It is clear from equation 40.2 that the highest proportion of weaving traffic to non-weaving traffic will give the minimum capacity. Let the proportion of weaving traffic to the non-weaving traffic in West-North direction be denoted as  $p_{WN}$ , in North-East direction as  $p_{NE}$ , in the East-South direction as  $p_{ES}$ , and finally in the South-West direction as  $p_{SW}$ . Then,

$$p_{WN} = \frac{370+550+500+520}{350+370+550+500+520+420} = \frac{1740}{2510} = 0.69$$

$$p_{NE} = \frac{420+500+700+300}{520+400+420+500+700+300} = \frac{1920}{2840} = 0.676$$

$$p_{ES} = \frac{450+550+700+520}{200+450+550+700+520+300} = \frac{2220}{2720} = 0.816$$

$$p_{SW} = \frac{450+300+370+420}{550+450+400+370+420+350} = \frac{1540}{2540} = 0.606$$

Thus the proportion of weaving traffic to non-weaving traffic is more in the East-South direction.

Therefore, the capacity also need to be found only for that section.

From equation 40.2,  $Q_{ES} = \frac{280 \times 13.5 [1 + \frac{10}{13.5}] [1 - \frac{0.816}{3}]}{1 + \frac{13.5}{54}} = 3830.56 \text{ veh/hr.}$